



FISH-EYES

CAUSES:

- too high drying temperature
- too short drying time between coats
- too thick primer coat
- unsuitable mixing and incorrect spraying technique
- air in the paint film
- contaminated air or machinery
- inadequate substrate preparation
- use of unsuitable thinners

PREVENTION:

- adopt application techniques and material preparation as stated in the technical data sheet
- check cleanliness of the machineries
- use recommended thinners

RESTORATION:

- remove coating, clean the substrate and repaint it