



## INTERCOAT ADHESION

---

### **CAUSES:**

---

- inadequate cleaning of the surface, presence of humidity or remaining contaminants (e.g. oil)
- application of a too thick layer of paint
- incorrect substrate preparation
- use of non-recommended thinners
- incorrect drying and/or curing temperatures

### **PREVENTION:**

---

- clean the surfaces thoroughly
- follow the technical data sheet instruction
- use recommended solvents

### **RESTORATION:**

---

- remove coating, clean the substrate and repaint it