



POOR ABRASION RESISTANCE

CAUSES:

- low quantity of paint applied
- incorrect paint mixing
- incorrect flash-off/curing temperatures

PREVENTION:

- follow application instructions on data sheet

RESTORATION:

- remove coating, clean the substrate and repaint it